

USER INSTRUCTIONS

D30-series Compact Digital Positioner

FCD PMENIM0030-05-A5 - 05/25

Installation
Operation
Maintenance





Contents

1.	Introduction3							
2.	Warning4							
3.	Storage6							
4.	Unpacking6							
5.	Description7							
6.	Principle of operation8							
7.	Type sign example9							
8.	D30 Order code10							
о.	ט טטע		10					
o. 9.								
	Install	ation	11					
	Install 9.1	ation	11 12					
	Install 9.1 9.2	ation	11 12					
	9.1 9.2 9.3 9.4	Air Connection Electrical connections Wiring and grounding quidelines	11 12 20 21					
	9.1 9.2 9.3 9.4	ation	11 12 20 21 24					
	9.1 9.2 9.3 9.4	ation	11 12 20 21 24					
	9.1 9.2 9.3 9.4 9.5 9.6	Air Connection Electrical connections Wiring and grounding quidelines	11 12 20 21 24 24 25					
9.	9.1 9.2 9.3 9.4 9.5 9.6 9.7	ation	11 12 20 21 24 24 25 25					

11.		nance/service					
	11.1	Disassembling D30 Circuit boards (PCB)	44				
	11.2	Circuit boards (PCB)	45				
	11.3	Limit Switches	46				
	11.4	Valve block	47				
	11.5	Pressure sensors (option)	47				
	11.6	Valve block Pressure sensors (option) Potentiometer	48				
12.	Trouble	eshooting					
13.	Techni	cal data	.50				
14.	Dimen	sional Drawing	.52				
15.	Spare	parts	.53				
16.	Declaration of Conformity55						
17.	Control Drawing 56						
18.	Annex:	Diagnostic Alarms	58				
19.	. Contact List61						



1. Introduction

The D30-series is a double acting digital positioner designed primarily for controlling modulating valves. The positioner can be used with single acting actuators with either rotary or linear movement.

The D30-series can be equipped with modules for limit switches and pressure gauges. The modules can be factory assembled before delivery or fitted later.

The D30 covers most actuators, from the smallest to the largest.

The modules for limit switches can contain one of the following:

- · Two mechanical contacts
- · Two proximity switches
- . Two inductive sensors

See Page $\underline{21}$, $\underline{22}$ and $\underline{51}$ for more options available.



Note: Only qualified technicians (according to IEC 60079 series of standards) are allowed to work with certified products.



2. Warning



Special Conditions for Safe Use

The enclosure of PMV D30-series Intrinsically safe version is made of aluminum and any impact or friction caused by external objects shall be avoided in the application. Control Drawing D4-086C contains the parameters for intrinsic safety. The intrinsic safe circuits D30-series is insulated from earth and complies with the dielectric strength test of 500 V ac.

Special Conditions for Safe Use (ATEX/IEC specific)

The surface area of the plastic parts on the cover exceeds the limits specified in EN 60079-0 for II 1G (EPL Ga) for gas group IIC and intensive rubbing or brush charging should be avoided when used in an IIC explosive atmosphere.

In a hazardous environment where there is a risk of explosion, electrical connections must comply with the relevant regulations.

Do not disconnect equipment unless area is known to be non-hazardous. or; read, understand and adhere to the manufacturer's live maintenance procedures. To prevent ignition of flammable or combustible atmospheres, disconnect power before servicing,

Substitutions of components may impair suitability for hazardous (classified) locations.

Special Conditions for Safe Use (FM specific)

For Intrinsically Safe applications: Use linear barrier only.

Potential risk of sparking from aluminum alloy enclosure. In Division 1 or Zone 0 installations, equipment shall be installed in such manner as to prevent the possibility of sparks resulting from friction or impact against the enclosure.

Potential risk of electrostatic sparking. Clean only with a damp cloth.

Environmental requirements

Some switch options may decrease the temperature working range see Control Drawing D4-086C for details.





Maintenance/service

Warnina!

When upgrading electrical parts inside a PMV positioner approved for installation in Hazardous locations special procedures apply, permission from PMV/Flowserve is required prior to the start of work. Please contact a Flowserve office for information regarding proper procedures. www.pmv.nu or infopmv@flowserve.com

Always turn off the air and electrical supplies before starting any work.

Always turn off the air and electrical supplies (input signals) when shutting down the PMV positioner for any purpose.

General safety

Safety instruction

Read the safety instructions in this manual carefully before using the product. The installation, operation, and maintenance of the product must be done by staff with the necessary training and experience. If any questions arise during installation, contact the supplier/sales office before continuing work.

Warning

The valve can open or close very quickly when in operation and, if handled incorrectly, may cause damages to fingers. There may also be unintentional effects due to it fully opening or shutting off the flow in the process pipe. Please note the following:

- If the input signal fails or is switched off, the valve operates guickly to its default position.
- If the compressed air supply fails or is turned off, rapid movements can occur.
- The valve is not controlled by the input signals when in the Out of Service mode. It will open/ close in the event of an
 internal or external leak.
- If a high value is set for Cut off, fast movements can occur.
- When the valve is controlled in the Manual mode, the valve can operate quickly.
- Incorrect settings can cause self-oscillation, which can lead to damage.

Important

- Always turn off the compressed air supply before removing or disconnecting the air supply connection or the integral filter. Remove or disconnect with care as air connection "C-" is still under pressure even after the air supply is turned off
- Always work in an ESD (Electrostatic Discharge) protected area when servicing the Printed circuit boards (PCB's).
 Make sure the input signal is switched off.
- The air supply must be free from moisture, water, oil and particles according to DIN/ISO 8573-1-2010
- Failure to comply with instructions specified in this IOM leads to warranty void.
- Work on D30 can void the warranty.



3. Storage

General

The D30-series positioner is a precision instrument. Therefore, it is essential that it is handled and stored in the correct way. Always follow the instructions in this IOM!

Note: As soon as the positioner is connected and started, internal air venting will provide protection against corrosion and prevent the ingress of moisture. For this reason, the air supply pressure should always be kept on unless repair/maintenance work of the positioner, actuator or valve equipment is in progress.

Storage indoors

Store the positioner in its original packaging. The storage environment must be clean, dry, and cool (-40°C to 80°C. -40°F to 176°F).

Storage outdoors or for a longer period

If the positioner must be stored outdoors, it is important that all the cover screws are tightened and that all open ports/connections are properly sealed and/or plugged.

The red shipping plugs are not intended as a permanent outdoor plug. The unit should be packed with a desiccant (silica gel) in a plastic bag or similar, covered with plastic, and not exposed to sunlight, rain, or snow.

4. Unpacking

Each delivery includes a packing slip. When unpacking, check all delivered valves and accessories using this packing slip. The packing slip shall match order.

Report transport damage to the carrier immediately.

In case of discrepancies, contact your nearest FLOWSERVE location.



5. Description

PMV D30-series is a double acting digital positioner that suits both linear and rotary actuators. It's modular and flexible design allows mounting according to the both standard VDI/VDE 3845 for rotary and IEC 534-6 & Flowtop for linear actuators with integrated tubing.

Further on, PMV D30 offers feedback capability with optional plug in switches, HART communication and auto calibration for simple and trouble free commissioning.





6. Principle of operation


The PMV D30 positioner is a digital positioner with various options. The positioner consists of three main modules:

- The microprocessor-based electronic control module includes direct local user interface buttons.
- 2. The nozzle and flapper-based electropneumatic converter module.
- 3. The infinite resolution valve position sensor.


The complete control circuit is powered by the two-wire, 4-20 mA command signal. The analog 4-20 mA command is passed to the microprocessor, where it is compared to the measured valve stem position. The control algorithm in the processor performs control calculations and produces an output command to

the electropneumatic converter module, which drives the pneumatic amplifier. The pneumatic amplifier controls the airflow to the actuator.

The change of pressure and volume of the air in the actuator causes the valve to stroke. As the valve approaches the desired position, the difference between the commanded position and the measured position becomes smaller and the output to the electropneumatic converter module is decreased. This, in turn, causes the pneumatic amplifier to close and the resulting flow to decrease, which slows the actuator movement as it approaches the new commanded position. When the valve actuator is at the desired position, the pneumatic amplifier is held at its balance pressure, which holds the valve in a constant position.




Air relay



D30 Positioner Principle



7. Type sign example



Ratings and Marking

D30 ATEX/IEC certification ATEX 11142X/IECEx PRE 17.0046X temperature range and marking: II 1 G Ex ia IIC T4 Ta -40°C to 85°C Ga

D30 US/CA FM certification FM18US0180X and FM18CA0082X marking:

IS CI. I Div.1 Gr. A-D T4 Ta CI. I Zone O AEx/Ex ia IIC T4 Ga Ta CI. I Div.2 Gr. A-D T4 Ta CI. I Zone 2 IIC T4 (US Only) Ta

Listing Company:

PMV Automation AB Korta Gatan 9 SE-171 54 SOLNA SWEDEN



D30 Order code

A = Model no	
D 3 0 full LCD menu, LED status	
B = Approval, Certificate	
D General purpose version	
E Intrinsically Safe Ex ia IECEx	
A Intrinsically Safe Ex ia ATEX	
B Intrinsically Safe Ex ia INMETRO	
N Intrinsically Safe Ex ia CCC	
M Intrinsically Safe Ex ia CCOE	
F Intrinsically Safe Ex ia FM	
C = Function	
H High Flow - Single/double acting - Spool valve	
D = Connections Air, Electrical	
G 1/4" G air, M20 x 1,5 electrical	
M 1/4" NPT air, M20x1,5 electrical	
N 1/4" NPT air, 1/2"NPT electrical	
E = Connection feature	
2 2 Electrical conduits	
T 2 Electrical conduits, threaded Aux. ventilation F = Housing material/ Surface treatment	
U Aluminium/Powder epoxy, black	
G = Mounting options / Shaft	
R M Remote mounting (position sensing unit sold separately)	
0.9 Double D type, adaptor spindle	
2.1 NAF shaft, including Mounting bracket D4-As920	
2 3 VDI/VDE 3845 rotary, Mounting kit not included	
3 0 Adaptor shaft, select between 01/06/26/30/36	
3 9 IEC 534-6, Flat D type, nut incl. Mounting kit not included	
H = Cover and Indicator	
PVA PMV,Black cover, Arrow indicator (Not when G = RM)	
PVB PMV, Black cover, No indicator	
F W A Flowserve, White, Arrow indicator (Not when G = RM)	
F W B Flowserve, White, No indicator	
I = Temperature/seals	
U -40°C to 80°C	
J = Input signal/Protocoll	
4 4-20 mA / none	
5 4-20 mA, / HART	_
P Profibus PA	
F Foundation Fieldbus	
K = Feedback option, switches	
X No Feedback option T 4-20 mA transmitter only (Only when J = 4 or 5)	
T 4-20 mA transmitter only (Only when J = 4 or 5) S* Limit switches Mechanical SPDT + 4-20mA transmitter	
N* Namur V3 type sensor, P+F NJ2-V3-N + 4-20mA transmitter	
P* Limit switches Proximity SPDT + 4-20mA transmitter	
5* Slot type Namur sensor, P+F SJ2-SN + 4-20mA transmitter	
6* Slot type Namur sensor, P+F SJ2-N + 4-20mA transmitter	
L = Options. Add in electronics	
0 No pressure sensors	
3 3 pressure sensors for advanced diagnostics	
M = Accessories	
X No accessories	
M Gauge block 1/4" G (DA, 3 gauges included)	
N Gauge block 1/4" NPT (DA, 3 gauges included)	
N= Special Options	
N No special options	<u> </u>
S Exhaust silencers	
T 270 deg rotary version (no shaft spring)	
U 270 deg rotary version (no shaft spring) + Exhaust silencers	
A A A B C D E - F G G H H H - I J K L I	M N
A A A B C D E - F G G H H H H - I J K L I	VI IV

Note: For latest version of valid model code please see www.pmv.nu

^{*} When J = P or F, only switches will be included, no 4-20 mA transmitter.

* When G = RM, this option is not selectable. Switches can be installed as position sensing unit.



9. Installation

Removal of cover

General purpose / Intrinsically safe

Remove cover by first loosening the screw (1) and then the two screws (2).

To install cover, first tighten the screw (1), then the two screws (2).

Tighten to 0.7 Nm \pm 15%.



Air Preparation

Supply air should meet requirements specified on <u>page 5</u>. In order to have best performance and durability we recommend to install a combined filter/regulator in front of the supply air connection. Connect the air supply to the filter, which is connected to the D30 positioner.

Tubing

It is recommended to use tubes with a minimum inner diameter of \emptyset 6 mm (1/4").

Gauge block

Gauge blocks are available for D30 series with ¼" NPT air connections. To install, ensure seals are aligned, then use 3 Nm (2.2 lb ft) of torque when fastening the gauge block to the positioner using the two screws supplied with the kit.

Gauge ports are available for D30 series with 1/8" NPT

Air supply requirements

Note: Poor quality air supply is the main cause of problems in pneumatic systems.

The air supply must be free from moisture, water, oil and particles and delivered @ 1.4-8 Bar (20-85 psi)

Standard: *DIN/ISO 8573-1-2010*Filtered to 5 Micron, dew point -40°C/F
Oil 1mg/m³ (0.83 ppm by weight)

The air must come from a refrigeration dried supply or be treated in such a way that its dew point is at least 10°C (18°F) below the lowest expected ambient temperature.

Before the air supply is connected to the positioner, we recommend the pipe/tube is opened freely for 2 to 3 minutes to allow any contamination to be blown out. Direct the air jet into a large paper bag to trap any water, oil, or other foreign materials. If this indicates that the air system is contaminated, it should be properly cleaned before continuing.



WARNING! Do not direct the open air jet towards people or objects because it may cause personal injury or damage.





9.1 Mounting


Note: If the positioner is installed in a hazardous environment, it must be of a type approved for this purpose.

All versions of the D30 positioner have an ISO F05 footprint (A). The holes are used to attach the D30 to the mounting bracket (B). Please contact PMV or your local distributor representative with actuator specifics for the proper mounting bracket and hardware.


The spindle shaft S09 (C) can be used to suit various actuators in question by the use of adapters.

It is important that the positioner's spindle shaft and the lever arms, that transfer the actuator movements, are correctly mounted. Any tension between these parts can cause incorrect operation and abnormal wear.

Spindle shafts





Note: There are many spindle options available depending on the actuator. Please contact your local PMV supplier for all options available.





Adapter drawing Suit shaft style "09"







9.1.1 Linear pneumatic actuator

9.1.1.1 Mounting on a linear pneumatic actuator

The mounting of a rod actuator kit (according to NAMUR/IEC 534 part 6) is described in an example by using the following equipment:

Valve: Standard globe valve or equivalent


Actuator: Single- or double acting pneumatic

actuator

Positioner: PMV D30 with mounting kit.

Pre-assembly: Valve with actuator (valve stroke is matched with the actuator stroke).

For mounting, proceed as follows:



Mounting the Follower Arm (Figures 1 and 2)

- Unscrew the lock nut for the follower arm attachment.
- Place the follower arm on the shaft at the back of the positioner and fasten it with the lock nut. The follower pin should point back from the positioner.




CAUTION: Maximum torque

0.25 Nm (0.18 ft-lbs).

Mounting the stem clamp bracket and take-off arm

(Figure 1)

- Attach the stem clamp bracket to the stem clamp and fasten it with two hexagon socket screws and lock washers.
- Attach the take off arm to the stem clamp bracket and fasten it with a hexagon socket capscrew and a washer. Ensure the take-off arm slot is centered.







Mounting the positioner (figure 1)

- 1. Adjust the actuator to mid-stroke.
- Pre-assemble the mounting bracket on the left actuator leg hand-tight with two U-bolts, nuts and lockwashers.
- Attach the positioner to the pre-assembled mounting bracket and fasten it with two hexagon head screws and two lock washers. Check that the follower pin is inserted in the slot of the take-off arm and the follower arm is positioned at a right angle to the outer edge of the positioner.
- 4. Tighten all screws and nuts.

Note: A slight unsymmetrical mounting increases the linearity deviation but does not affect the performance of the device. Depending on the actuator size and stroke it may be necessary to flip the take-off-arm (Figure 4) by 180° and attach it to the opposite side of the stem clamp bracket.







Follower pin adjustment (figure 4)

The positioner follower pin must be adjusted to match the valve stroke in the following manner:

- Adjust the follower pin (STROKE + 10 mm) as indicated on the follower arm's embossed scale (Figure 2).
- 2. Exhaust the actuator.
- Loosen the follower pin and shift it along the follower arm until the control marking on the feedback gear (Figure 3) is horizontal (points to the center of the feedback potentiometer). Fasten the follower pin in this position.
- 4. Adjust the actuator to full stroke and check the follower pin adjustment the same way as described in step 3. As the actuator strokes, the rotation of the feedback gear should be between the inner control markings. If the length of rotation is outside the control markings, adjust the follower pin farther out on the feedback lever to reduce the angle of rotation.

NOTE: Stroke the actuator carefully and ensure the follower arm does not interfere with valve parts, actuator or positioner. Do not adjust the follower pin too near to the slot end of the take-off arm.

The minimum lateral distance should be approximately 5 mm (0.2 inches) to prevent bending of the feed-back mechanisim.




9.1.1.2 FlowTop direct mounting


- 1. Fit block (7) and (10) together with screw (17) and make sure 0-Ring is installed.
- 2.Remove screw from top position.
- 3. Install block (7), (10) assembly to the positioner together with o-ring (12).
- 4. Secure housing with the screws (13).
- 5. Install complete assembly to the actuator with bolts (14) and 0-rings (19),(20) and make sure lever arm (6) connects with pin (3).

 NOTE Tightness 2.3 Nm
- 6. Install plug (9).
- 7. Gauges (8) can be installed, remove plug 18.





Pin plate and pin configuration for different actuators and stroke



10 mm stroke 252

20 mm stroke 252

20 mm stroke 502

40 mm stroke 502



9.1.2 Rotary actuators

9.1.2.1 Mounting the positioner on a quarterturn actuator (closed or open by spring)

The mounting of a pneumatic double-piston partturn valve acutator (in accordande with VDI/VDE 3845) is described as an example by using the following equipment:


Quater-turn valve acutator: Rack and pinion or scotch yoke, closed or open by spring.

9.1.2.2 VDI/VDE 3485 (NAMUR)

Mount bracket *(1)* to positioner. Secure with 4 x M6 screws *(2)* 2.5 Nm (1.8 ft lbs)

Fit positioner on actuator and secure with 4×3 screws (3).


Install tubing (4) between actuator and positioner.





9.1.3 Remote Mounting

Tube mounting




Wall mounting



Ordering Part Number - D3R-AS6

Hole pattern



View below






DS/DM Remote pick up

- Dome indicator (Option)
- Spring Loaded shaft
- 2 x Limit Switches
- Ex d or Ex ia
- Alu or Stainless steel



9.2 Air Connection


Must be plugged when converting to single action function.



External air Connection Port S Port C+ Port C- Supply air, 1.4-8 barg (20-115 psi) Connection to actuator, opening Connection to actuator, closing (only for double action) Plug for single action

Single acting positioner, Direct function Actuator with closing spring


When the control signal increases, the pressure C+ to the actuator is *increased*. The valve stem moves upward and rotates the positioner spindle *counter-clockwise*. When the control signal drops to zero, C+ is vented and the valve closes.



Reverse function


Actuator with opening spring

When the control signal increases the pressure C+ to the actuator is *increased*. The valve stem moves downward and the positioner spindle rotates *clockwise*. When the control signal drops to zero, C+ is vented and the valve opens.



Double acting positioner, Direct function Double acting actuator


When the control signal increases, the pressure C+ to the actuator is increased. The valve stem is pressed upward and rotates the positioner spindle counter-clockwise. When the control signal is reduced, the pressure C- to the actuator increases and the valve spindle is pressed downward. If the control signal disappears, the pressure goes to C-, C+ vents, and the valve closes.






9.3 Electrical connections


Terminal block diagram for the D30-series. The terminal block (right) for the positioner is accessible when the aluminum cover is removed.



Remove the black plug with a coin or slotted head screwdriver



D30 optional Switch or remote board








Warning! In a hazardous environment where there is a risk of explosion, electrical connections must comply with the relevant regulations.




	Switch option	Terminal Block pin number					
		5	6	7	8	9	10
Х	No feedback option	na.	na.	na.	na.	na.	na.
T	4-20 mA transmitter, no switches	na.	na.	na.	na.	na.	na.
5	Slot type NAMUR sensor, P+F SJ2-SN	-	+	na.	-	+	na.
6	Slot type NAMUR Sensor, P+F SJ2-N	-	+	na.	-	+	na.
N	NAMUR V3 type sensor, P+F NJ2-V3-N	-	+	na.	-	+	na.
Р	Limit switches Proximity SPDT	NO	NC	Com	NO	NC	Com
S	Limit switches Mechanical SPDT	NC	NO	Com	NC	NO	Com

M	ountir	na n	nti	nnc

RM Remote Board (Feedback and switch option na. na. na. CCW	RM	Remote Board (Feedback and switch option	na.	na.	na.	CCW	RA	CW




Connection of mechanical and proximity switches. (S,P)




Connection of NAMUR switch. (N,5,6)

Remote Unit



Requires shielded cable shorter than 10 m or 30 feet




Connection of remote unit



Limit switch calibration

- Loosen screws (1) and adjust cams.
- Adjust lower cam first and then upper cam.
- Tighten screws with torque 0.3 Nm (1).





9.4 Wiring and grounding guidelines

Cable requirements: 24–16 AWG, 0,25 mm² - 1,5 mm² · gauge wire sizes should be used for connection to the terminals. Wire sizes outside of this gauge range may not form a good connection or may cause damage to the terminals.

For installation practices and allowable cable lengths refer to the latest version of the HART Field Communications Protocol Application Guide, HART HCF LIT.

Input signal: 4 – 20 mA

Observe the minimum requirements of voltage and equivalent electrical load:

8 VDC at 20mA non HART version

9,4VDC at 20 mA HART version

The performance is ensured only for a minimum input current of 3,6mA.

The input loop current signal to the D30 positioner is recommended to be in shielded cable. By tying shields to ground at only one end of the cable removes environmental and electrical noise. Connect the shield wire to the source. Shield wire should be insulated and ensure that is not connected to positioner side.

For Profibus, see page 29

For Foundation Fieldbus, see page 31

9.5 Grounding Screws

The grounding screws, located inside the positioner cover and near the electrical conduit connections, should be used to provide the unit with an adequate and reliable earth ground reference. Tie this ground to the same earth ground reference as the electrical metallic conduit. Additionally, the electrical metallic conduit should be earth grounded at both ends of its run.

Note: Any of the positioner ground screws must not be used to terminate signal shield wires. Shield wires should be terminated only at the signal source.





9.6 Electromagnetic compatibility


The PMV D30 digital positioner has been designed to operate correctly in electromagnetic (EM) fields found in typical industrial environments. Care should be taken to prevent the positioner from being used in environments with excessively high EM field strengths (greater than 10 V/m). Portable EM devices such as handheld two-way radios should not be used within 30 cm of the device.

Ensure proper wiring and shielding techniques of the control lines, and route control lines away

from electro-magnetic sources that may cause unwanted noise.

An electromagnetic line filter can be used to further eliminate noise.

In the event of a severe electrostatic discharge near the positioner, the device should be inspected to ensure correct operability. It may be necessary to recalibrate the PMV D30 positioner to restore operation.



9.7 Compliance voltage

Output compliance voltage refers to the voltage limit the current source can provide. A current loop system consists of the current source, wiring resistance, barrier resistance (if present), and the PMV D30 impedance.

The PMV D30 requires that the current loop system allow for a 8.0 - 9.4 VDC drop across the positioner at maximum loop current.



CAUTION: Never connect a voltage source directly across the positioner terminals. This could cause permanent circuit board damage.

In order to determine if the loop will support the PMV D30, perform the following calculation:

 $Voltage = Compliance Voltage(@Current_{MAX})$

$$- Current_{MAX}(R_{barrier} + R_{wire})$$

To support the PMV D30 the calculated voltage must be greater than 9.4 VDC for D30 HART and 8 VDC for non-HART.

Example: DCS Compliance Voltage = 19 V

$$R_{\text{barrier}} = 300\Omega$$

$$R_{wire} = 25\Omega$$

$$CURRENT_{MAX} = 20 \text{ mA}$$

Voltage =
$$19 \text{ V} - 0.020 \text{ A}(300\Omega + 25\Omega) = 12.5 \text{ V}$$

This system will support the PMV D30, as the voltage 12.5 V is greater than the required 8 VDC for non-HART and 9.4 VDC for HART.



10. Control

10.1 D30 5 Push Buttons

The positioner is controlled using the five push buttons and the display, which are accessible when the aluminum cover is removed.

For normal functioning, the display shows the current value. Press the ESC button for two seconds to display the main menu.

Use the push buttons to browse through the main menu and the sub-menus.

The main menu is divided up into a basic menu and a full menu.

10.1.1 Other functions ESC

Exit the menu without making any changes (as long as any changes have not been confirmed with OK).

FIINC

To select function and change parameters.

OK

To confirm selection or change of parameters.

MENU INDICATOR

Displays the position of the current menu row in the menu.

IN SERVICE


The positioner is following the input signal. This is the normal status when the positioner is working.

OUT OF SERVICE

The positioner is not following the input signal. Critical parameters can be changed.

MANUAL

The positioner can be stroked manually using the push buttons. See section "Man/Auto", page 36.



UNPROTECTED

Most of the parameters can be changed when the positioner is in the "Unprotected" position. However, critical parameters are locked when the positioner is in the "In service" position.

LED color (R=Red, Y=Yellow, G=Green)

Co	des d	durin	g In Service
		R	Actual valve position deviates from requested/ set position
		Υ	Fully opened/closed valve using Cut Off (= OK)
		G	Controlling valve position (= 0K)

Со	des a	lurin	g Out of service
	R	Υ	Input signal not calibrated
	Υ	G	Feedback signal not calibrated
	Υ	Υ	Out of Service (= OK)

Ca	Calibration alarm						
	R	G	No feedback movement. Check linkage from actuator to positioner				
	R	Υ	No air available. *(alarm available only when pressure sensors installed)				
R	G	G	No pot connection. Check pot cable inside positioner.				
R	Υ	Υ	No air relay. Check cable inside positioner.				
R	Υ	G	Pot not calibrated. Go to Calibrate->Expert->Pot on LCD menu.				



10.1.2 Menu indicator

There are indicators at both sides of the display window and they indicate as follows:

Flashing in position *Out of service*

Flashing in position *Manual*

Displayed in position Unprotected

The indicators on the right-hand side show the position in the current menu.

10.1.3 Menus

To display the menus you can select:

- Basic menu, which means you can browse through four different menu items
- Full menu, which comprises ten steps. Use the Shift Menu to browse through the menu items

Full Menu can be locked out using a passcode.

The main menus are shown on the next page and the sub-menus on the subsequent pages.

10.1.4 Changing parameter values

Change by pressing $\langle \rangle$ until the desired figure is flashing.

Press to step to the desired figure. Confirm by pressing OK.

A change can be undone by pressing the *ESC* button, which returns you to the previous menu.

FULL MENU MAN/AUTO


FULL MENU CALIBRATE

FULL MENU


SHIFT MENU



10.1.5 Menu System



The menus are described on the following pages.







First start

"Calibrate" is displayed in the basic menu automatically, the first time power is applied. It can be selected from the basic or full menu at any time.

Tip! Instant guick calibration

The D30 can be instantly calibrated by pressing the top + bottom buttons for 5 seconds (see picture). This function is available from any menu position.

A complete auto-calibration will take a few minutes depending on size of actuator and includes end limit calibration (zero and span), auto-tuning (dynamically sets the control parameters for the actuated package the positioner is controlling) and a check of the movement speed. Start the automatic calibration by selecting *Auto-Cal* and then answer the questions in the display by pressing *OK* or the respective arrow. After calibration, position performance can be adjusted by changing gain setting. See page 32.

Calibration error messages

If a fault occurs during calibration, one of the following error messages can be displayed:

No movement/press ESC to abort

Typically the result of an air delivery issue to the actuator, a stuck valve or actuator, or incorrect mounting and/or linkage arrangement. Check for proper supply air to the positioner, pinched tubing, proper actuator sizing, proper linkage and mounting arrangement.

Pot uncalibrated/press ESC to abort

The potentiometer is out of range. The potentiomenter is aligned using the Calibrate - Expert cal - pot Menu. The calibration sequence must be restarted after the fault is corrected.



Instant quick calibration

First start. Profibus PA

For Profibus PA, connect the input signal at pos 1 and 2 on the terminal block. See Electrical connections in the manual.

In the SETUP/Devicedata/Profibus: change the address from 126 to any number between 1-125. Never use the same number with more than one unit. Install values in failsafe mode, for communication when loss of signal. Calibrate the unit. GSD files are available at our web-page www.pmv.nu

To install the D30_PROFIBUS.DDL file to Siemens SIMATIC PDM.

- Move the files to the directory where the DeviceInstall.exe is located.
- 2. Run DeviceInstall.exe



Parameter	Description		BYTE
SP	Setpoint	The SP has 5 bytes, 4 bytes for the float value and one status byte. The status byte needs to be 128 (0x80Hex) or higher for the D30 to accept it.	4+1=5
READBACK	Position	The READBACK has 5 bytes, 4 bytes for the float value and one status byte.	4+1=5
POS_D	Digital position	Returns actual position as a digital value with definitions as below 0 = Not initialized 1 = Closed 2 = Opened 3 = Intermediate	2
CHECKBACK		Detailed information of the device, coded bit wise. Several messages can occur at the same time.	3
RCAS_IN	Remote Cascade	The RCAS_IN has 5 bytes, 4 bytes for the float value and one status byte.	4+1=5
RCAS_OUT	Remote Cascade	The RCAS_OUT has 5 bytes, 4 bytes for the float value and one status byte.	4+1=5

Status Byte Table

MS	В	LSI	В				Meaning	D30 info	
0	0	0	0	1	0	Х	X	Not connected	
0	0	0	0	1	1	Х	X	Device failure	PROFIBUS PA module failure
0	0	0	1	0	0	Х	X	Sensor failure	No sensor value
0	0	0	1	1	1	Х	X	Out of service	Al Function Block in O/S mode
1	0	0	0	0	0	X	X	Good - Non cascade	Measured value OK All Alarm values used
1	0	0	0	0	0	0	0	OK	
1	0	0	0	1	0	0	1	Below low limit Lo	Advisory alarm
1	0	0	0	1	0	1	1	Above high limit Hi	Advisory alarm
1	0	0	0	1	1	0	1	Lo-Lo	Critical alarm
1	0	0	0	1	1	1	1	Hi-Hi	Critical alarm

Example SP = 43.7% and 50%

Float	Нех	Status
43.7	42 2E CC CD	80
50.0	42 48 00 00	80



(FF) Foundation Fieldbus function blocks

Function blocks are sets of data sorted by function and use. They can be connected to each other to solve a control process, or to a controlling DCS. To get a good introduction and understanding of FF look at www.fieldbus.org and download the "Technical Overview" from the obove FF pages.

(TB) Transducer Block

The TB contains unit specific data. Most of the parameters are the same as parameters found on the display. The data and the order of data varies between different products. The AO-block setpoint (SP) and process value (PV) parameters are transceived to the TB through a channel. The TB has to be in AUTO for the AO-block to be in AUTO.

The positioner has to be in menu-auto mode and in service to be controlled from the Fieldbus. If the positioner is placed in menu-manual mode then the transducer block will be forced to (LO) local override. In this way a person in the field will be able to control the positioner from the keypad, without collision with a control loop.


(RB) Resource Block

The RB is a set of parameters that looks the same for all units and products. The values of the RB define unit information that concerns the Fieldbus Protocol such as MANUFAC_ID which informs the unique manufacturer id. For Flowserve it is 0x464C53. The RB has to be in AUTO for the AO-block to be in AUTO.

(A0) Analogue Output Block

The AO follows Fieldbus Foundation's standard on content and action. It is used for transferring (SP) setpoints from the bus to the positioner.

CAS_IN (cascade input) and RCAS_IN (remote cascade input) are selected as inputs to the AO block depending on the MODE_BLK parameter. The selected input will be relayed to the SP parameter of the AO block. BKCAL_OUT (back calculated output) is a calculated output that can be sent back to a controlling object so that




control bumps can be avoided. Usually the BKCAL_OUT is set to be the (PV) process value of the AO-block, i.e. the actual measured position of the valve. OUT is the primary calculated output of the AO block. During a limited action (ramping) of the AO block the RCAS_OUT parameter will supply the final setpoint and the OUT parameter will be the limited output. The transducer block is connected through a channel to the AO block. Through this channel the OUT value and SP are transceived.

In order to set the AO block to AUTO, the TB and the RB have to be in AUTO. Further the AO block has to be scheduled. Using National Instruments Configurator; scheduling can be done by adding the unit to a project and then click on the "upload to device" icon.

To write a setpoint value by hand, add Man to MODE->Permitted parameter, and then choose MODE->Target to Man. Make sure that the unit is scheduled.

Example

A typical FF block loop control might look like the following: Where the positioner is represented by the AO-block.







The contents of the menu are shown on the next page. The various menu texts are described below.

Auto-Cal Auto-tuning and calibration of end positions

Start tune Starts the tuning. Questions/commands are displayed during

calibration. Select the type of movement, function, etc. with and confirm with OK as shown in the chart on the next page.

Lose prev value? OK? A warning that the value set previously will be lost (not during the

first auto-tuning).

Direction? Air-to-open. Select for direct function.

Direction? Air-to-close. Select for reverse function.

In service? Press OK Calibration finished. Press OK to start positioner functioning.

(If ESC is pressed, the positioner assumes the "Out of service"

position but the calibration is retained).

TravelCal Calibration of end positions

Start cal Start end position calibration.

Lose prev value? OK? A warning that the previously set value will be lost. Confirm with

OK. The calibration sequence starts.

In service? Press OK Calibration finished. Press OK to start positioner functioning.

(If ESC is pressed, the positioner assumes the "Out of

service"position but the calibration is retained).

Perform Setting gain

Normal 100% gain


Perform G, F, E, D, C, B, A Possibility to select a lower or higher gain in steps.

Default setting is D. A is the lowest gain and G is the highest.

Note: Original P. I. D. will always be shown in display



Feedback option Calibration of the 4-20 mA transmitter



4-20 mA transmitter value will not be displayed in D30 LED. Only on external mA Meter.



Expert Calibration

When entering "ExpertCal" mode - walk through the list of parameters described below.

Set values where applicable. Confirm by pressing OK.

Set point LO: Use the calibrator set to 4 mA (or set another value on the display). Press OK.

Set point HI: Use a calibrator of 20 mA (or set another value on the display). Press OK.

Pressure LO: Use a supply of 1.4 bar (20 psi) (or set another value on the display). Press OK. Pressure read out only possible on D30 with built in pressure sensor.

Pressure HI: Use a supply of 8 bar (115 psi) (or set another value on the display). Press OK. Pressure read out only possible on D30 with built in pressure sensor.

Transmitter: Connect 10 - 28 VDC. Connect an external mA meter to the loop. Read low value on mA meter and adjust with up/down key. Press OK to set low value. Repeat procedure to set High value.

Also see video on www.pmv.nu

Pot: Potentiometer setting, see section 5. Also see video on www.pmv.nu

Full reset: Resets all set values and enters Factory mode. To reset the values only, use FACT SET in main menu, see below



The menu contents are shown in the figures on the right and the texts are described below:



Current values can be read using the Read Menu and some values can be reset.

Pos Shows current position Set&pos Set point and position **READ** Set&dev Set point and deviation pos Shows position graph Pos araph Temp Shows current temperature Statistics n cycles **Statistics** READ n cycles Shows number of cycles. set&pos Statistics 1 cycle = [move of valve pulse rate +change direction+move opposite direction] regardless of size of each move/stroke. Statistics acc travel Travel = [accumulated % valve Acc travel has moved/100]. Statistics READ mean dev Example: move 60% up + move set&dev 40% down =>Acc travel = 1 Statistics mean dev Shows accumulated m. abs dev READ deviation in % Pos Graph Statistics m.abs dev Shows accumulated runtime absolute deviation in % READ # of resets Shows number of resets temp Statistics # of resets Shows accumulated runtime runtime since last reset READ Statistics Statistics extr. temp Extr temp Shows extreme min and max temperature Statistics Shows position and time for Histogram READ histogram position value Alarms Alarms Displays tripped alarms Statistics Reset stat





The Man/Auto menu is used to change between manual and automatic modes.

The menu contents are shown in the figures on the right and the various texts are described below:

AUT, OK = MAN

Positioner in automatic mode

MAN, OK = AUT

Positioner in manual mode


In the *MAN* mode, the value of POS can be changed using . The push-buttons increase/decrease the value in steps. The value can also be changed in the same way as for the other parameter values, as described on page 30.

Other functions

C+ can be fully opened by pressing \triangle and then immediately *OK* simultaneously.

C- can be fully opened by pressing \longrightarrow and OK simultaneously.

C+ and C- can be fully opened for blowing clean by pressing and *OK* simultaneously.



Note: When changing between *MAN* and *AUT* mode, the *OK* button must be pressed for 3 seconds.






The Shift Menu is used to choose between the basic menu and the full menu.

The menu contents are shown in the figures on the right and the various texts are described below:

No Full menu selected.

Yes Basic menu selected.



Note: The Menu can be locked with a passcode, see Setup menu.



The Status Menu is used to select whether or not the positioner is in service.


The menu contents are shown in the figures on the right and the various texts are described below:

o o service Not in service. Flashing

indicator in upper lefthand corner of display.

in service Positioner in service.

Critical parameters cannot be changed.



Note: When changing between *In service* and *Out of service*, the *OK* button must be pressed for 3 seconds.

у

Qo

Sar

Lin

Eq%





The Setup Menu is used for various settings.

The menu contents are shown in the chart on the next page and the various texts are described below:

Actuator	Type of actuator	Size of actuator	Time out
Rotating	Rotating actuator.	Small	10 s
Linear	Linear actuator.	Medium	25 s
		Large	60 s
		Extra large	180 s

Lever Only for linear actuator.

Lever stroke Stroke length to achieve correct display. Input only needed in case display value is off

Level cal Calibration of positions to achieve correct display.

Direction

Direct Direct function (signal increase opens). Indicator/spindle rotates counter-clock wise.

Reverse Reverse function.

Character Curves that show position as a function of input signal.

Linear Equal % Quick open Sqr root

See diagram.

Custom Create own curve.

of point

Movement Cust chr Specify number of points (3, 5, 9, 17, or 33) Enter values on X and Y axes. **Cust curve** Χ Signal

Curr range (Use this function to split range)

0% = 4.0 mA100%=20.0 mA

Possibility of selecting which input signal values will correspond to 0% and 100% movement respectively.

Examples of settings: 4 mA = 0%, 12 mA = 100%, 12 mA = 0%, 20 mA = 100%.



Start menu Start in Basic menu or Trvl range Setting end positions Select Out of Service. 0% = 0.0%Full menu. Set percentage value for Orient Orientation of text on display. desired end position Par mode Display of control parameters (e.g. 3%). such as P, I, D or K, Ti, Td. Set 0% Select In Service. Devicedata Connect calibrator. HW rew Move forward to desired end SW rew General parameters. position (0%) and press OK. Capability 100%=100.0% Select Out of Service. Set percentage value for desired end position HART Menu with HART parameters. (e.g. 97%). Only amendable with HART communicator. It is possible Set 100% Select In Service. to read from display. Connect calibrator, Move forward to desired end position (100%) Profibus PA and press OK. Status Indicates present status Tryl ctrl Behavior at set end position Device ID Serial number Set low Choose between Free Address 1-126 (positioner will control until a Allotted ID Tag mechanical top is reached). Descriptor ID description Limit (stop at set end position), and Cut off (Default Date SW release date value. Go directly to a Failsafe Value = preset pos mechanical stop at a Time = Set time +10sec= redefined setpoint). time before movement Set high Similar to Set low. Valve act = failsafe (preset pos) or last value **Values** Select position for Cut off and (present pos) Limit at the respective end Alarm out= 0n/0ffpositions.

Passcode

Setting passcode for access to the menu

Numbers between 0000 and 9999 can be used as passcodes. 0 = no passcode required.

Appearance

On display

Language Select menu language.

Units Select units.

Def. Display Select value(s) to be

displayed during service. The display reverts to this value 10 minutes after any

change is made.

Foundation Fieldbus

Device ID Serial number

Nod address Address on the bus provided

by the DCS system

TAG-PD TAG Name provided by the

DCS system


Descriptor D30 positioner Date SW release date Sim iumper Simulate iumper, FF

simulation functionality

activated = 0N







The menu contents are shown in the chart on the next page and the various texts are described below:

Close time Minimum time from fully open to closed.

Open time Minimum time from closed to fully open.

Deadband Setting deadband. Min. 0.1%.

Expert Advanced settings.

Control See explanations below.

Togglestep Test tool for checking functions. Overlays a square wave on the set value.

Self test Internal test of processor

Undo You can read last 20 changes.

P,I,D and K,Ti,Td parameters

If one of the gains is changed, the corresponding value in the other gain set is changed accordingly.

See diagram below!





The menu contents are shown in the chart on the next page and the various texts are described below:

Deviation Alarm generated when deviation occurs

On/Off Alarm on/off.

Distance Allowed distance before alarm is generated.

Time Total deviation time before alarm is generated.

Alarm out Select ON/OFF offers output on terminals.

Valve act Behavior of valve when alarm is generated.

Limit 1 Alarm above/below a certain level.

On/Off Alarm on/off.

Minipos Setting of desired min. position.


Maxpos Setting of desired max. position.

Hysteresis Desired hysteresis.

Alarm on Select ON/OFF offers output on terminals.

Valve act Behavior of valve when alarm is generated.

Limit 2 See Limit 1.





Temp Alarm based on temperature
On/Off Temperature alarm on/off.
Low temp Temperature setting.
High temp Temperature setting.
Hysteresis Allowed hysteresis.

Alarm out Select ON/OFF offers output on terminals. Valve act Behavior of valve when alarm is generated.

Valve act

No action Alarm generated only. Operations not affected.

Goto open Valve moves to 100%. Positioner changes to position Manual.


Goto close Valve moves to 0%. Positioner changes to position Manual.

Manual Valve stays in unchanged position. Positioner moves to position Manual.




The menu contents are shown in the chart below.

The default values that were set on delivery can be reset using the Fact Set menu. Values from calibration and from other settings will then be lost.









11. Maintenance/service

When carrying out service, replacing a circuit board, etc., it may be necessary to remove and refit various parts of the positioner. This is described on the following pages.

Read the Safety Instructions on page 4 and page 5 before starting work on the positioner.

Cleanliness is essential when working with the positioner. Contamination in the air ducts will inevitably lead to operational disturbances. Do not disassemble the unit more than that described here.

DO NOT disassemble the valve block apart because its function will be impaired.

When working with the D30 positioner, the work place must be equipped with ESD protection before the work is started.

Work on D30 can void the warranty



Always turn off the air and electrical supplies before starting any work.



Please see section for special conditions for safe use and spare parts on page 5!


Please contact a Flowserve office for information regarding proper procedures. www.pmv.nu or infopmv@ flowserve.com

11.1 Disassembling D30

Removing cover and inner cover

- Unscrew the screws (A) and remove the cover. When mounting cover see <u>page 5</u>. Torque the screws to 0.7 Nm.
- Pull off the arrow pointer, (B).
- Unscrew the screws (C) and remove the inner cover. In reinstalling the inner cover, torque the screws to 0.3 Nm.
- If equipped with switches remove the cam stack

Note: Removing inner cover will void warranty.







11.2 Circuit boards (PCB)



Warning! Disconnect or switch off the electric power supply before starting any work.


- Lift off the display PCB..
- · Very carefully release the cable connections
- . Unscrew the two screws B and lift up the circuit board.
- In reinstalling the circuit board, torque the screws to 0.3 Nm.





11.3 Limit Switches

Loosen two x screws holding the plastic cover and remove the screws. Pull out the plastic cover. Break away the plastic protection located on the main plastic cover to ensure there is an opening for the switches/cams. In reinstalling the plastic cover, torque the screws to 0.3 Nm.



When installing the switch card, make sure it is placed correctly. Secure the PC Board with the two screws holding the plastic cover. Make sure the holes are centered before tightening the screws. Torque the screws to 0.3 Nm.

Note: When installing the cam assembly for mechanical switches, retract both switch arms first.

Install the cam assembly and tighten the screws loosely to obtain enough friction to lock the cams.

Adjust the lower cam first, then the upper cam. See <u>page 23</u>.







11.4 Valve block



Warning! Turn off the air and electric power supply before starting any work.

Remove the three screws (A) and lift out the valve block

Note: Do not disassemble the valve block

 When installing the valve block — torque the two screws to 0.4 Nm and seal with Loctite® 222.

11.5 Pressure sensors (option)

Pressure sensors are available as an option. They indicate pressure for supply and C+, C- air, and is used by ValveSight TM to enable advanced valve diagnostics.

The sensors are mounted on a circuit board which mounts next to the air relay on the floor of the housing using three screws. Torque the screws to 0.4 Nm.

Remove 3 screws from the positioner's housing. Insert pressure sensor board including o-rings into the housing. Tighten the 3 screws. Insert ribbon cables to the pressure sensor board and positioner's main board.





Pressure sensor PCB - top view






11.6 Potentiometer 90° (270°) spring loaded potentiometer

The spring-loaded potentiometer can be removed from the gearwheel for calibration or replacement.

If the potentiometer is replaced or the setting is changed, it must be calibrated.

- Select the menu Calibrate Expert Cal pot.
 The display shows Set gear.
- Turn the spindle shaft clockwise to end position and press OK. Either turn manually or use the up/down arrows (with supply air) to stroke the positioner to turn the shaft clockwise.
- Turn shaft counterclockwise manually or by using up-down key. Ensure large gear goes to mechanical stop.
- Move spring (1) aside and disengage cogwheels. Turn potentiometer according to display until OK is shown. Press OK. See drawing below.
- Move back spring (1) and secure potentiometer (2) calibration. See drawing below. Spring (1) must allow a small play but not so big that the cogs can disengage.





Potentiometer and cogwheel for 90° rotation



12. Troubleshooting

Symptom	Action		
Input signal change to positioner does not affect actuator position.	 Check air supply pressure, air cleanliness, and connection between positioner and actuator. Out of service, in manual mode. Check input signal to positioner. Check mounting and connections of positioner and actuator. 		
Change in input signal to positioner makes actuator move to its end position.	Check input signal. Check mounting and connections of positioner and actuator.		
Inaccurate control.	 Perform Auto-calibration and check for any leaks. Try high and low gain settings. Uneven air supply pressure. Uneven input signal. Wrong size of actuator being used. High friction in actuator/valve package. Excess play in actuator/valve package. Excess play in mounting of positioner on actuator. Dirty/humid supply air. 		
Slow movements, unstable regulation.	Implement auto-tuning. Increase the deadband (Tuning menu). Adjust Performance (Calibrate menu).		



13. Technical data

Rotation angle	min 25° max 100°
Stroke	From 5 mm (0.2")
Input signal	4-20 mA DC
Air supply	1.4-8 barg (20-115 psi) DIN/ISO 8573-1 3.2.3 Free from oil, water and moisture.
Air delivery	Up to 760 nl/min @ 6 bar (29.3 scfm @ 87 psi)
Air consumption	8 nl/min @ 6 bar (0.31 scfm @ 87 psi)
Air connections	1/4" G or NPT
Cable entry	2x M20x1.5 or ½" NPT
Electrical connections	Screw terminals 2.5 mm2 /AWG14
Linearity	<0.4%
Repeatability	<0.5%
Hysteresis	<0.3%
Dead band	0.1-10% adjustable
Display	Graphic, view area 15 x 41 mm (0.6 x 1.6")
UI	5 push buttons
CE directives	2014/30/EU, 2014/35/EU, 2014/34/EU
Voltage drop, w/o HART	8 V
Voltage drop, with HART	9.4 V
Enclosure	IP66 , NEMA 4X
Material	Die-cast Aluminum
Surface treatment	Powder coating
Temperature range	-40°C to 85°C (-40°F to 185°F)
Weight	1.8 kg (4 lbs)
Mounting position	Any
Communication protocols	Hart, Profibus PA, Foundation Fieldbus



Mechanical switches	
Туре	SPDT
Size	V3
Rating	3 A/250 VAC / 1A@30VDC
Temperature range	-40°C to 80°C (-40°F to 176°F)

NAMUR sensors	
(NJ2-V3-N)	
Туре	Proximity DIN EN 60947-5-6:2000
Load current	1 mA ≤ <i>I</i> ≤ 3 mA
Voltage range	8,2 VDC
Hysteresis	0.2%
Temperature range	-25°C to 80°C (-13°F to 176°F)


Proximity switches		
Туре	SPDT	
Rating	0.4 A @ 24 VDC, Max 10 W	
Operating time	Max 1.0 ms	
Max voltage	200 VDC	
Contact resistance	0.2 Ω	
Temperature range	-40°C to 80°C (-40°F to 176°F)	

Slot NAMUR switches		
(SJ2-SN, SJ2-N)		
Туре	Proximity DIN EN 60947-5-6:2000	
Load current	1 mA ≤ <i>I</i> ≤ 3 mA	
Voltage	8,2 VDC	
Hysteresis	0.2%	
Temperature range	-25°C to 80°C (-13°F to 176°F) SJ2-N -40°C to 80°C (-40°F to 176°F) SJ2-SN	

4-20 mA transmitter	
Supply	11-28 VDC
Output	4-20 mA
Resolution	0.1%
Linearity full span	+/-0.5%
Output current limit	30 mA DC
Load impedance	800 Ω @ 24 VDC



14. Dimensional Drawing






15. Spare parts

No	Part no	Description
1	D4-SP37PVA	Black cover incl. screws and flat indicator
1	D4-SP37FWA	White cover incl. screws and flat indicator
2	D4-SP40	Internal cover incl. screws
3	D4-SP1516	External covers SST, 2, incl screws
4	3-SXX	Spindle adaptor (XX = 01, 02, 06, 26, 30, 36)
5	D4-SP05-09	S09 shaft compl. incl. gear wheel, friction clutch, spring
5	D4-SP05-21	S21 shaft compl. incl. gear wheel, friction clutch, spring
5	D4-SP05-23	S23 shaft compl. incl. gear wheel, friction clutch, spring
5	D4-SP05-39	S39 shaft compl. incl. gear wheel, friction clutch, spring
6	D4-SP400	Air relay complete, incl. cable, seal, screws
7	D4-SP08	Potentiometer compl. incl. spring, bracket, cable
8	3-SP37HR	PCB LCD assembly
9	D4-SP7-80H	PCB mother board 4-20 mA / HART
9	D4-SP7-80P	PCB mother board Profibus PA
9	D4-SP7-80F	PCB mother board Fieldbus
10	D4-SP84-3	Pressure sensor assembly complete
11	D4-SPGB	Bag with screws, O-rings, seals, pair of sintered brass silencers, cable gland
12	D4-SP940M	Gauge block G, complete incl. screws, seals, 3 gauges / SST, Brass
12	D4-SP940N	Gauge block G, complete incl. screws, seals, 3 gauges / SST, Brass
13	D4-SP081 S	Limit switches Mechanical SPDT compl.
13	D4-SP081 N	Limit switches Namur V3 P&F NJ2-V3-N compl.
13	D4-SP081 P	Limit switches Proximity SPDT compl.
13	D4-SP081 5	Limit switches Namur slotted P&F SJ2-SN compl.
13	D4-SP081 6	Limit switches Namur slotted P&F SJ2-N compl.

Note: Replacement of certified spare parts require proper qualification and knowledge of applicable standards.







16. Declaration of Conformity



EU Declaration of Conformity

We. PMV Automation AB. Korta Gatan 9, SE-171 54 Solna, declare under our sole responsibility that, our product,

D30 - Digital Valve Positioner

is in conformity with the following harmonized legislation:

2014/30/EU - Electromagnetic compatibility (EMC) directive, based on conformity with the requirements of harmonized standards:

EN 61000-6-2:2005 EN 61000-6-2:2005/AC:2005, EN 61000-6-4:2007, and EN 61000-6-4:2007/A1:2011

The product is also evaluated by PMV to comply with the following standards:

EN IEC 61000-6-2:2019, and EN IEC 61000-6-4:2019

2014/35/EU - Low voltage (LV) directive¹, based on conformity with the requirements of harmonized standards:

EN 60204-1:2018

2014/34/EU - Equipment for explosive atmospheres (ATEX) directive, based on conformity with the requirements of harmonized

Intrinsically safety EN IEC 60079-0:2018, and EN 60079-11:2012

Conformityassessment procedures, Modul B and Mode D of the ATEX directive, have been carried out, and the following Notified Bodies attest the compliance of our product type(s) and of the quality assurance of the involved production processes respectively:

EU-type examination

NB 2460 DNV Product Assurance AS

Veritasveien 1, 1363 Høvik, Norway

Quality assurance

NEMKO Group AS Philip Pedersens vei 11, 1366 Lysaker, Norway

Product marking(s)

Certificate(s)

Model code(s)

II 1 G Ex ia IIC T4 Ga -40°C≤T_a≤+85°C

Presafe 17 ATEX 11142X Issue 1 Nemko 03ATEX4122Q²

D3xAxxx-xxxxxxx-xxxxxx

Singed for and on behalf of: PMV Automation AB

Ulf Nylund Quality Manager


Solna, Sweden,

Ul pylend

1 The directive, 2014/35/EU, on the safety of low voltage equipment only appli safety.

2 The certificate of the quality assurance system of the manufacturing pro-

17. Control Drawing



Class I,II Division 1 Group A,B,C,D T4 Class I Zone 0,1 AEx ia IIC T4 Class I Division 2 Group A,B,C,DT4 Class I Zone 2 AEx n IICT4 Class III Div 1&2 T4

INSTALLATION NOTES:

Control equipment connected to the associated apparatus shall not use or generate more than 250Vrms or Vdc. Associated apparatus manufacturer's installations drawing shall be followed when installing this equipment. Run shielded interconnection cable with shield connected to FM approved associated apparatus ground.

The intrinsically safety entity concept:

Allows the interconnection of two intrinsically safe devices FM approved with entity parameters not specifically examined in combination as a system when:

Jo or Voc or Vt ≤ Vmax, lo or lsc or It ≤ Imax, Po ≤ Pi, Ca or Co ≥ Ci + Ccable, La or Lo ≥ Li + Lcable

Allows the interconnection of non-incendive field wiring apparatus with associated non-incendive field apparatus, Jo or Voc or V1 < Vmax, lo or lsc or It < Imax, Po < Pi, Ca or Co > Ci + Ccable, La or Lo > Li + Lcable. using any of the wiring methods permitted for non-hazardous (unclassified) locations when: The non-incendive field wiring concept:

The non-incendive: Use IS values as general (Vmax = Ui ; Imax = II) except for folowing Namur Switch (Pos K=5,6,N or U)

Vmax = 25V, Imax is not regired for this current controling circut Vmax = 30V, Imax = 500mA Proximity Switch (Pos K=P)

4-20mA input signal (Pin 1 and 2)

Vmax= 30V, Imax =40mA

Vmax= 30V, Imax is not regired for this current controling circut 4-20mA Output signal Pin 3 and 4

or division 1 installations:

The configurations of associated apparatus shall be FM approved under entity concept. installation of intrinsically safe systems for hazardous (classified) locations" and the Division1 installations should be in accordance with ASI/ISA RP12.06.01

or division 2 installations:

national electrical code (ANSI/NFPA 70).

Using non-incendive field wiring concept, the associated apparatus shall be FM approved under entity concept or non-incendive field wiring concept.

non-incendive field wing concept. If the unit is installed in accordance with the national electrical code (ANSI/NFPA 70) for division 2 wiring methods excluding non-incendive field wiring. The associated apparatus is not required to be FM approved under entity concept or

(Including IEC related Certificates)


4

The enclosure of PMV D30(D20) Intrinsically safe version is made of aluminium and any impact or friction caused by external objects shall Special Conditions for Safe Use be avoided in the application.

The intrinsic safe circuits D30(D20) is insulated from earth and complies with the dielectric strength test of 500 V ac. The surface area of the plastic parts on the cover exceeds the limits specified in EN 60079-0 for II 1G (EPL Ga) for gas group IIC and intensive rubbing or brush charging should be avoided when used in an IIC explosive atmosphere. The cable connection of the Remote Unit with the D30(D20) unit shall be type A or B in accordance with EN 60079-25. The cable must be temperature rating for the ambient temperature range at the site. adequately mechanically protected in all instances and have a

General requirements for units with 4 conduit openings and NPT threading. Model code position D=N and Position E= 4 or F

Cable glands may not be installed on the same level. the unused openings must be plugged by supplyed A maximum of two cable glands may be used, Cable glands must be used when installing. blanks or other suitable blanks. (se ilustration)



Sheet 2:2

18. Annex: Diagnostic Alarms

Online diagnostic alarms	D3	D30/D30E	D22	D30
Actuator parts worn out	X	Х	Х	X
Auto PST failed	X	X	X	X
C- leakage	X		X*	Χ*
C- pressure sensor failure	X		X*	X
C+ leakage	X		X*	Χ*
C+ pressure sensor failure	X		Х*	X
Calibration error	X	Х	X	X
Control out of tune	X	X	Х	Х
CPU failure or memory failure	X	X	Х	X
Current sensor failure	X	X	X	X
Deviation	X	X	X	X
Deviation of lower spring range	X		Х*	Х*
Deviation of lower travel range	X		X*	X*
Deviation of upper spring range	X		X*	X*
Deviation of upper travel range	X		X*	X*
Excessive closing force	X		X*	X
Excessive number of cycles	X	Х	X	X
Excessive number of high cutoffs	X	X	X	X
Excessive number of low cutoffs	X	X	X	X
Excessive number of piezo valve pulses	X	Α	Λ	Α
Excessive opening force	X		Х*	X
Feedback linkage failure	X	X	X	X
Feedback linkage play	X*	^	X*	X*
Foreign object in valve	X		X*	X*
High air consumption	X		Α	, A
High current	X	X	X	X
High cutoff failure	X	^		X*
High EP stress	X	X	X	, A
High friction	X	^	X*	X*
High friction at closed position	X		X*	X*
High supply pressure	X		X*	X
Leakage between C+ and C-	X		X*	X
Limit 1	X	X	X	X
Limit 2	X	X	X	X
Low available force	X	^	X*	X*
Low CPU voltage	X	X	X	X
Low cutoff failure	X	^	X*	X*
Low friction	X		X*	X*
Low supply pressure	X		X*	X
Manual mode	X	X	X	X
Out of service	X	X	X	X
Packing worn out	X	X	X	X
Position vs. pressure difference	X	^	X*	X
Potentiometer failure	X	X	X	X
Potentiometer not calibrated	X	X	X	X
Pressure sensor disconnected	X	^	X*	X
Seat worn out	X	X	X	X
Set worn out Setpoint oscillation	X	X	X	X
Small minimum pulse parameter	X	^		X*
Spring range deviation	X		X*	X*
Spring too weak to reach failsafe position	X		X*	X*
Stuck valve	X		X*	X
Supply pressure sensor failure	X		X*	X
		V		
Temperature	X	X	X	X
Temperature sensor failure	X	X	X	X
Travel span deviation	Х			I

 X^{\star} Require pressure sensor for diagnostics

Note: For more information, please check the ValveSight IOM.







FCD PMENIM0030-05-A5 - 05/25

To find your local Flowserve representative please use the Sales Locator

System found at www.flowserve.com

Flowserve Corporation has established industry leadership in the design and manufacture of its products. When properly selected, this Flowserve product is designed to perform its intended function safely during its useful life. However, the purchaser or user of Flowserve products should be aware that Flowserve products might be used in numerous applications under a wide variety of industrial service conditions. Although Flowserve can provide general guidelines, it cannot provide specific data and warnings for all possible applications. The purchaser/ user must therefore assume the ultimate responsibility for the proper sizing and selection, installation, operation, and maintenance of Flowserve products. "The purchaser/user should read and understand the user instructions included with the product, and train its employees and contractors in the safe use of Flowserve products in connection with the specific application.

While the information and specifications contained in this literature are believed to be accurate, they are supplied for informative purposes only and should not be considered certified or as a guarantee of satisfactory results by reliance thereon. Nothing contained herein is to be construed as a warranty or guarantee, express or implied, regarding any matter with respect to this product. Because Flowserve is continually improving and upgrading its product design, the specifications, dimensions and information contained herein are subject to change without notice. Should any question arise concerning these provisions, the purchaser/user should contact Flowserve Corporation at any one of its worldwide operations or offices.

For more information about Flowserve Corporation, contact www.flowserve.com or call USA 1-800-225-6989.

@ May 2025, Flowserve Corporation, Irving, Texas

PMV Automation AB Korta Gatan 9 SE-171 54 SOLNA SWEDEN

Phone: +46 (0)8-555 106 00 E-mail: infopmv@flowserve.com