

ACCORD CONTROLS

Aviator II Valve Controller

Installation
Operation
Maintenance

FCD ACENIOM0100-02

Mechanical Installation: Installation is best performed with the NAMUR mounting kits. These kits allow direct mounting of the Aviator™II shaft to the actuator pinion without a coupler. The NAMUR mounting kits will work with any actuator conforming to the NAMUR standard for accessory mounting hole locations and pinion dimensions. Simply attach bracket to actuator and Aviator™II to bracket with the included fasteners. The Aviator™II shaft features an integral alignment pin which engages the tapped pinion hole. Accord also offers a full line of non-NAMUR kits.

Electrical Connections: The Aviator™II features three (3) 3/4" NPT conduit entries. The switches and pilot solenoid are pre-wired to the screw terminal block to simplify customer wiring connections. A wiring diagram is included under the lid. Simply make desired connections to the screw terminal blocks. Secure a grounding wire under the green grounding screw. Make sure the solenoid control voltage is the same as the solenoid electrical rating. For hazardous locations, U.L. and National Electric codes require an approved sealing fitting within 18 inches of the switch enclosure. Sealing fittings are not required for Division 2 non-incendive applications. Open conduit entries must be closed after installation using a close-up plug approved for hazardous locations. Conduit and plugs must engage a full five (5) threads.

For field wiring: ensure that any excess wire lengths or loops are routed away from any moving parts and are short enough, or secured to ensure a 1/4" clearance between the wire and the inside surface of the switchbox cover.

Spool and Tubing Configuration: For spring return actuators, a 4-way spool valve is provided with port #2 plugged. For double acting actuators, the same spool valve is provided with no plugs. Make sure the correct spool is selected before installing tubing. (Note: the APS2 module can be supplied on spring return actuators to purge the spring chamber with supply air.) 2. Make sure all air pressure is removed before installing tubing. 3. Attach tubing according to Figures 1 or 2 below, depending upon application. Attach supply tubing to Port 1 and use 3 and 5 exhaust. 4. To prolong actuator life use only clean, dry plant air. Lubricated air is not required, although it is recommended particularly for high cycle applications.

NOTE: A minimum of 35 psi is required to operate the spool valve.




Figure 1
Double Acting Actuator

Figure 2
Spring Return Actuator

Caution: To prevent ignition of hazardous atmospheres, keep cover bolts tight while circuits are live. Disconnect supply circuit before opening removing the lid. Do not place the lid with the flat surfaces down. This will ensure that the flange is not damaged and integrity of the flame path will be maintained.



Certifications: The Aviator II has the following globally accepted certifications:



SIRA 19ATEX1299X

Flame Proof  **II 2 G Ex db IIB T4/T3 IP 65 Gb**

Minimum Ambient Temperature : -20⁰C

Maximum Ambient Temperature :+40⁰C for T4 or +60⁰C for T3

Complies with the following standards:

EN IEC 60079-0:2018

EN 60079-1:2014 A/C:2018

IECEX SIR 20.0030X

Flame Proof **Ex d IIB T4/T3 Gb IP 65**

Minimum Ambient Temperature : - 20⁰C

Maximum Ambient Temperature :+40⁰C for T4 or +60⁰C for T3

Complies with standards

IEC 60079-0:2017, Edition: 7.0

IEC 60079-1:2014-06, Edition: 7:0



Explosion Proof

Class I Div 1 Groups C,D; Class I Div 2 Groups A,B,C,D, T4 Tamb -20 to +60C; Class II Div 1,2 Group E,F,G

US - Class 1 Zone 1, AEx d IIB T3/T4,

Canada - Class 1 Zone 1, Ex d IIB T3/T4

Special Hazardous Location Instructions:

For North America installations you must install a conduit sealing fitting within 18 inches of the enclosure to meet NEC regulations.

For ATEX and IECEx installations an appropriately rated Cable Gland is required. Any unused conduit entry must have a suitably rated blanking element.

CAUTION:

- Substitution of components may impair suitability for Zone 2 Increased Safety.
- Do not disconnect equipment unless power has been switched off or the area is known to be non-hazardous.
- Cleaning this housing by rubbing should be done in a non-hazardous area.
- Potential electrostatic charging hazard, clean only with a damp cloth – danger of propagating discharge.
- All grounding and bonding installation requirements must be addressed
- All installation, inspection, and maintenance of the equipment should be performed by suitably trained personnel. In addition, for ATEX, all installation, inspection, maintenance and repair must be done by suitably trained personnel. For more information refer to EN 60079-14:1997, EN 60079-17, EN 60079-19
- Replacement parts not to invalidate certification and to be only obtained direct from the manufacturer.

Special conditions of Use for ATEX

1. The following maximum constructional gaps are less than those required by table 2 of EN 60079-1:2004

Description	Type	Measured Gap Dimension (mm)	Maximum Required Gap Dimension (mm)	Referenced Manufacturer Document
Flat Joint between cover and base	Flat	.038 mm	.20 mm	XM0372, X01218, X01142, XM0401
Between Shaft and Cover	cylindrical	.088mm Diametrical Clearance	.20 mm	XM0372, X01218, X01142, XM0401
Between Shaft and Base	cylindrical	.088mm Diametrical Clearance	.20 mm	XM0372, X01218, X01142, XM0401

2. The tensile strength of the fastening bolts are detailed below:

(x4) Metric Hexagon Socket M8-6G Refer to Manufacturers Documentation X01265

Tensile Strength: 671 N/mm²



Switch Setting 1. Rotate actuator to desired position. 2. Loosen five captive cover screws and remove lid, turning slightly while lifting. 3. To adjust the limits, lift or depress cam against spring to disengage splines and turn cam until switch activates / deactivates as desired (Figure 3). 4. Release cam, assuring that the splines are engaged (A slight amount of force above the spring force may be needed). 5. Clean base and lid flanges and replace lid on base. Make sure wires are NOT caught between flanges, and tighten captive screws.





Figure 3
Cam Adjustment

Lubrication: All Aviator™ II spool valves are pre-lubricated and will operate dry (with no additional lubrication) The use of lubricated air will not interfere with the Aviator™II function.


If lubrication is used, the oils listed below are popular, easily obtainable fluids that are recommended for use with the Aviator™II Spool valve: Gulf Harmon 47, Mobil DTE Medium, Shell Tellus 29, Texaco Rondo B, Sohivis 47 and Sunnis 921. May other lubricants are acceptable providing they do not contain detergents that will attack Nitrile or Viton Seals.




AVIATOR II SWITCH OPTIONS




AVIATOR II WITH MECHANICAL SWITCHES




AVIATOR II WITH PHAZER SWITCHES




AVIATOR II WITH TYPE 4 SWITCH



AVIATOR WITH P&F NJ2 SWITCHES






AVIATOR II WITH AS-i/DeviceNET CARD




AVIATOR II WITH FF NETWORK CARD

SOLENOID OPTIONS






SPOOL VALVE OPTIONS



1.8 Cv Spool Option



4.5 Cv Spool Option



Flowserve Corporation
1350 Mountain Springs Parkway
Springville, Utah, Utah, 84663
801 489-8611

Bulletin FCD ACENIOM0100-02

To find your local Flowserve representative please
use the Sales Support Locator System found at
www.flowserve.com

Or call: 1-931-432-4021

Flowserve Corporation has established industry leadership in the design and manufacture of its products. When properly selected, this Flowserve product is designed to perform its intended function safely during its useful life. However, the purchaser or user of Flowserve products should be aware that Flowserve products might be used in numerous applications under a wide variety of industrial service conditions. Although Flowserve can provide general guidelines, it cannot provide specific data and warnings for all possible applications. The purchaser/user must therefore assume the ultimate responsibility for the proper sizing and selection, installation, operation, and maintenance of Flowserve products. The purchaser/user should read and understand the (INSERT OFFICIAL USER INSTRUCTION TITLE) instructions included with the product, and train its employees and contractors in the safe use of Flowserve products in connection with the specific application.

While the information and specifications contained in this literature are believed to be accurate, they are supplied for informative purposes only and should not be considered certified or as a guarantee of satisfactory results by reliance thereon. Nothing contained herein is to be construed as a warranty or guarantee, express or implied, regarding any matter with respect to this product. Because Flowserve is continually improving and upgrading its product design, the specifications, dimensions and information contained herein are subject to change without notice. Should any question arise concerning these provisions, the purchaser/user should contact Flowserve Corporation at any one of its worldwide operations or offices.

For more information about Flowserve Corporation, contact www.flowserve.com or call USA 1-800-225-6989.